

**Kurz Instruments, Inc
MFT B-Series v2.0
Menu Quick Lookup**

H	Home Key Back out of menu system
C	Clears Input in Program Mode Acknowledge Meter Event
P	Program Mode Page display
D	Display Mode Delete (backspace) in Program Mode
E	Enter key (accept user input)
	Function
	Key Sequence
	Basic Setup P-123456-E
	Advanced Setup (Menu Scroll) P-654321-E-1
	Advanced Setup (Quick Jump) P-654321-E-2
	see other side for commonly used Quick Jump Option #s
Basic Setup Menu Items	Tag Name
	Flow Units
	Flow Area
	Probe Depth (Ins. Meter)
	4-20 mA AO #1 Setup
	4-20 mA AO #2 Setup
	Setup Run Mode Display

Function	Option #
PROGRAM MODE (Quick Jump)	
Basic Meter Setup	1
Setup Flow Cutoff	2
Flow CF and TC	3
Setup Flow Totalizer	4
Setup 4-20mA AO #1	5
Setup 4-20mA AO #2 (NA in HART)	6
Setup Run Mode Display	7
Setup Relay Outputs	8
Setup Alarms	9
Setup Pulsed Output	11
Setup Sensor Purge	12
Calibrate Analog Outputs	14
Setup Drift Check	23
DISPLAY MODE (Quick Jump)	
Display Flow Meter Data	42
Display Input Voltage	44
Display Sensor Output	45
Display Model Number	34
Display Sensor Serial Number	32
Display Event Code	49
Display Firmware Version	50
www.kurzinstruments.com 800-424-7356	