



## Option 32 — Factory Sensor Setup

**Note:** This Option is used by Kurz for diagnostic and troubleshooting purposes.

To access the Factory Sensor Setup menu in Display mode:

1. Press **D**.
2. Press **2** to invoke the Quick Jump option.
3. Press **32** for the **Factory Sensor Setup** menu, and then press **E**.

---

```
SENSOR S/N
>FD93087A
```

---

The Sensor Serial Number prompt appears.

4. Press **P** to continue.

---

```
TC MODE
>CURRENT MODE  ^v
```

---

The TC Mode prompt appears.

5. Press **P** to continue.

---

```
SENSOR TYPE
>FD= 9/300 OHM  ^v
```

---

The Sensor Type prompt appears.

6. Press **P** to continue.

---

```
RPO
>C8.94390600  Ohm
```

---

The RPO prompt appears.

7. Press **P** to continue.

---

```
RTO
>299.800300  Ohm
```

---

The RTO prompt appears.

8. Press **P** to continue.



---

RX  
>76.5733000 Ohm

---

The RX prompt appears.

9. Press **P** to continue.

---

RY  
>34.0094000 Ohm

---

The RY prompt appears.

10. Press **P** to continue.

---

SENSOR MATERIAL  
PLATINUM 385

---

The Sensor Material prompt appears.

11. Press **P** to continue.

---

RP CSR  
>0.5000000 Ohms

---

The RP CSR prompt appears.

12. Press **P** to continue.

---

RTC CSR  
>150.000000 Ohms

---

The RTC CSR prompt appears.

13. Press **H** to exit.

The main Display mode (DSP) prompt appears.