



Option 25 — EEPROM Update

This option is used to update the firmware and can potentially remove any recent modifications made to the operation of the flow meter. This option should only be used when directed by Kurz Support.

To access the EEPROM Update menu in Program mode:

1. Press **P**.
2. Enter your **Advanced** access password, and then press **E**.
3. Press **2** to invoke the Quick Jump option.
4. Press **25** for the **EEPROM Update** menu, and then press **E**.

```
LOAD FROM EEPROM
>NO          ^v
```

The prompt for enabling an EEPROM update appears.

5. Press the arrow keys to select **NO** or **YES**, and then press **E**.

```
LOADING CONFIG
DATA FROM EEPROM
```

The prompt indicating the update appears.

6. Press **E** to return to the main Program prompt.